

## 05-19 Ford Super Duty 4WD Front lift kit instructions



- Step 1: Raise the vehicle and support the frame with jack stands.
- Step 2: Using a floor jack, support the front axle and disconnect both shocks at the lower mounts.
- Step 3: Disconnect the sway bar end links from the axle mount on both sides.
- Step 4: Remove the bolt that holds the brake line mounting bracket to the axle. Be sure not to remove the brake line from the caliper, this will cause excess work.
- Step 5: Lower the front axle far enough to remove the springs. Take note as to the position of the spring with a mark. It must be re-installed later in the exact same position after the spacer has been installed. Be sure not to lower the axle too far, do not put tension on the brake lines.
- Step 6: Remove the bolt holding the lower spring perch to the axle.
- Step 7: Place the spacer between the axle and the spring perch with the chamfered side down to the axle. Secure the spring perch and spacer using the bolts provided with the kit. We recommend a few drops of loctite on the threads, torque the bolts to 80 ft-lbs.
- Step 8: Re-install the springs making sure they are oriented the same as when they were removed.
- Step 9: Repeat steps 6 through 8 on the opposite side of the truck.
- Step 10: Raise the axle and reconnect the sway bar and both shocks.
- Step 11: Re-install the brake line mounting brackets. Mount the front tires.
- Step12: Lower truck from jack stands and be sure to torque lugnuts to factory specifications.
- Step 13: Recheck all work and test brakes before test driving.
- Step 14: Have an alignment performed as soon as possible.

## Terms and conditions Please read the following terms and conditions of use before using this product

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

## Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.