

Nissan Titan rear lift kit instructions



1. Chock the front wheels and jack up the rear of the vehicle. Support the vehicle with jack stands. Remove the rear tires and wheels.
2. Support the rear axle with a floor jack and remove lower shock bolts with a 21mm and then remove the factory u bolts.
3. Remove stock block and install the new blocks on the axle making sure the block and axle pin align.
4. Install the supplied u-bolts and hardware and secure to the correct factory torque specs.
5. Install rear shock back into location using a 21mm wrench

Terms and conditions

Please read the following terms and conditions of use before using this product

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.