

Toyota Tacoma/Tundra differential drop kit instructions



1. Remove the skid plate from the bottom of the truck.
2. Using a floor jack support the differential.
3. Remove the factory M14 bolts. Make sure you save the OEM dome washers.
4. Lower the differential far enough to insert the drop spacers. The differential may need to be pulled down to make enough room.
5. reinstall the differential using the new longer supplied bolts and nuts.
6. Reinstall the skid plate using the small new skid plate drop spacers and the new longer hardware.
7. Make sure to recheck the torque of all bolts once done.

Terms and conditions

Please read the following terms and conditions of use before using this product

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.