

2" F150 Rear Lift Kit instructions



1. Chock the front wheels and jack up the rear of the vehicle. Support the vehicle with jack stands. Remove the rear tires and wheels.
2. Support the rear axle with a floor jack and remove lower shock bolts and then remove the factory u bolts.
3. Lower the rear axle and insert the new rear lift block on top of the stock rear lift block making sure that the **smaller side of the taper is facing the front of the truck.**
4. Install the supplied U-bolts and hardware to the correct factory torque spec.
5. Reinstall the rear shocks.
6. Re check torque on all bolts after the truck has been driven 50 miles.

Terms and conditions

Please read the following terms and conditions of use before using this product

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.