

1999-2018 Silverado/Sierra 1500 Frame plugs

Step 1: Locate the two holes on each side of the truck on the inside of the rear fender well

Step 2: Remove any loose rust using a file.

Step 3: Test fit the plugs to insure a tight fit. If they are tight you are done!

Step 4: If the plugs are loose due to the amount of corrosion inside the frame tube then use silicone or gasket maker to create a snug fit.

