



## Magneride relocation Brackets



- Step 1: Locate the magneride linkage on the top of the control arm.
- Step 2: Disconnect the ball stud from the stock bracket on the top of the control arm.
- Step 3: Bolt the new relocation bracket to the stock bracket using the lower hole and the supplied hardware.
- Step 4: Reconnect the magneride linkage to the top hole in the bracket.