



Front Coil Spacers

07-18 Jeep Wrangler JK Lift Kit instructions

Front Installation

- 1: Use a jack to raise the front wheels off of the ground. Be sure to use proper jack stands
- 2: Remove the front wheels
- 3: Next emove the bottom sway bar bolts.
- 4: Remove the lower shock bolt.
- 5: Remove the brake line bracket
- 6: Push down on the axle to allow the coil spring to be removed. Also remove the factory spring isolator. 7:Install the new spacer over the bump stop and place the spring isolator between the new spacer and the Spring.

8:Reinstall the coil spring making sure to rotate it until the end hits the stop.

9:Install the rear brake line extension brackets using the hardware provided along with the stock hardware.

10:Install the shock extenders on the lower front mount. Using the supplied sleeves to go in the stock mounting location.

11:Reinstall the stock shock.

12: You can then make sure all hardware is torqued to factory spec, reinstall the tires.

13: Once on the ground you can reattach the sway bar.

14: The drag link must be adjusted to center BEFORE the vehicle is driven. Failure to do so will result in poor performance.

Rear Installation

- 1: Jack up the vehicle so the rear wheels are off the ground. Making sure to use proper jack stands.
- 2. Remove the upper and lower shock mount bolts and remove the factory shock.

3:Next remove the bottom sway bar bolts.

4:Remove the factory brake line bracket and install the brake line extension bracket.

5: Push down on the axle to remove the stock spring and spring isolator.

6: Install the new rear spacer using the supplied retainer to hold the rear spacer in place. The retainer gets placed up into the frame and the 1/2" bolt goes through the spacer to hold it in place.

7:Install the coil spring isolator and spring back into place making sure the end of the spring on the bottom mount is rotated to the stop.

8:Install the rear shock extensions using the supplied 10mm bolts.

9:Torque all hardware to factory specs and reinstall the wheels and tires.

Important notes

Draglink must be adjusted to center or the vehicles computer will show an error.

A front end alignment is required after the install.

Terms and conditions
Please read the following terms and conditions of use before using this product

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.