



Ford Bronco Lift kit instructions



Spacer thickness and lift amount is not a 1 to 1 ratio

Example: If you ordered a 2" kit the spacer will measure about 1.5" thick

Front Install instructions

Attention: The front and rear spacers are the same

- 1: Begin by jacking up the front of the vehicle and supporting it with jackstands.
- 2: Using a 15mm socket remove the 6 bolts holding the front skid plates onto the vehicle.
- 3: Next will be to remove the nut holding the swaybar end link to the lower control arm on both sides of the vehicle.
- 4: Remove the 4 bolts holding the sway bar to the frame using a 18mm socket and remove the sway bar from the truck.
- 5: Loosed the 3 nuts on the top of the strut. Do not remove them all the way.
- 6: Remove the two nuts on the lower strut mount.
- 7: The lower control arm bolts need to be removed next but first mark the alignment cams with a paint marker.
- 8: Using a floor jack support the front of the lower control arm. Then remove the lower control arm bolts.
- 9: Remove the 3 nut at the top of the strut and remove the strut from the truck.
- 10: There is a alignment pin on the top of the strut that needs to be removed. It can be pulled out with a set of pliers.
- 11: Mount the new lift spacers on top of the strut using the factory nuts.
- 12: Reinstall the strut back into the truck starting with the top bolts. Leave the bolts loose so there is some ability to move the strut.
- 13: Rotate the bottom of the strut so the bottom studs line up with the lower control arm.
- 14: Using a floor jack under the lower control arm reinstall the lower control arm bolts along with the alignment cams, lining up the marks that were made previously.
- 15: Torque the top and bottom strut mounts along with the lower control arm bolts to factory spec.
- 16: Repeat this process for the other side before reinstalling the sway bar and sway bar end links.
- 17: **A proper front end alignment is required after the install.**

Terms and conditions

Please read the following terms and conditions of use before using this product

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.