



Jeep Sun visor repair kit

You will need a T20 torx bit to remove the factory screws next to the visor post. And a #2 Phillips head screw driver to install the visor clip on each side. **YOU NEED TO REMOVE THE 'OUTBOARD' SCREW FIRST.....DO NOT REMOVE BOTH FACTORY SCREWS ON EACH VISOR YET!!! OR THE ENTIRE ASSEMBLY WILL COME DOWN!!!YOU WANT TO REMOVE AND REPLACE EACH SCREW ONE AT A TIME.**

To make your work easier....flip the sun visors to the forward position and set in place on both ends, this will allow easy access to the work area.

For the drivers side, take the clip that has the opening to the right and install the screw with a Phillips head screw driver.....do not tighten yet, just make it semi snug. NOW.....remove the factory screw on the other side of the post. Then, rotate the clip opening to capture the band on the post of the visor. (You will now need to rotate the visor towards you to have access to the other screw) Insert the Phillips head screw and snug up....check your work and then tighten both screws.

Repeat this same operation on the passenger side using the remaining clip and two screws.