

Magneride relocation Brackets



Step 1: Locate the magneride linkage on the top of the control arm.

Step 2: Disconnect the ball stud from the stock bracket on the top of the control arm.

Step 3: Bolt the new relocation bracket to the stock bracket using the lower hole and the supplied hardware.

Step 4: Reconnect the magneride linkage to the top hole in the bracket.

MotoFab Lifts 2400 Walden Ave Buffalo NY 14225
Email: info@motofablifts.com PH:800-430-8674
Quality Leveling and Lift Kits accessories

MADE IN THE USA!!!