

Chevy Trailblazer/Envoy

Front and Rear Install instructions

Front Spacers

Front Install Instructions

- 1: To begin install, block the rear tires of the vehicle so that the vehicle is stable and can't roll backwards. Safely lift the front of the vehicle and support the frame with jack stands. Place jack stands on both sides of the vehicle and remove both front tires.
- 2:Loosen the lower strut mounting bolt. Leaving the nut on the bolt.
- 3:Strike the bolt with a hammer to loosen the bolt from the lower control arm.
- 4:Disconnect the sway bar end links.

Rear Spacers

- 5:Remove the upper ball joint pinch bolt and nut.
- 6:Strike the side of the upper control arm to separate the ball joint.
- 7:Remove the upper strut mounting hardware and remove the entire strut from the vehicle.
- 8:Place the new spacer on top of the strut and bolt it into place using the stock hardware.
- 9:Loosen the lower strut mount pinch bolt and rotate the strut 180 degrees.
- 10:Reinsert the strut back into the vehicle.
- 11:Reattach the upper ball joint and sway bar end links.
- 12:Torque all bolts to factory spec and recheck them after 25 miles.

Rear Install Instructions

- 1: To begin install, block the rear tires of the vehicle so that the vehicle is stable and can't roll backwards. Safely lift the rear of the vehicle and support the frame with jack stands. Place jack stands on both sides of the vehicle of the vehicle stands.
- 2:Place a jack under the center of the rear end for support.
- 3:Disconnect the ABS wiring at the frame so there is enough slack in the lines.
- 4:Disconnect the sway bar end links.
- 5:Disconnect the rear lower shock mounts.
- 6:Slowly lower the axle so you can remove the rear coil springs.
- 7:Place the new rear spacer between the OE isolator and the coil spring.
- 8:Raise the rear end so you can reconnect the lower shock mount and the sway bar end links.
- 9:Torque all bolts to factory spec and recheck them after 25 miles.

Terms and conditions Please read the following terms and conditions of use before using this product

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.