

## Dodge Rear Lift kit instructions



- Step 1: Loosen the lug nuts and jack the truck up.
- Step 2: Put jackstands under the frame as far rear and high as possible.
- Step 3: Support the axle with a floor jack under the rear differential.
- Step 4: Remove rear tires.
- Step 5: Unbolt the lower shock bolt.
- Step 6: Unbolt the sway bar from the axle bracket.
- Step 7: Lower the rear axle.
- Step 8: The coils should be loose, but not loose enough to pull out.
- Step 9: Jack up one side of the axle forcing the other side to drop even closer to the ground.
- Step 10: Remove the coil.
- Step 11: Place spacer on top of the lower coil bucket.
- Step 12: Put coil back into place(forcefully)
- Step 13: Repeat on opposite side.
- Step 14: Jack the axle up from the differential to align the shocks and reinstall bolts.
- Step 15: Reinstall the sway bar bolts.
- Step 17: Remove jackstands.
- Step 18: Lower truck to the ground.
- Step 19. Retighten lug nuts.
- Step 20. It is recommended to take your vehicle to an alignment shop to have it realigned.

Terms and conditions

**Please read the following terms and conditions of use before using this product**

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

**Limitation of Liability**

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.