



## 4Runner Rear Lift Kit Instructions

Step 1: Jack up the rear of the truck and remove the rear wheels.

Step 2: Support the rear axle using a jack.

Step 3: Remove the upper sway bar bolt on both sides of the truck.

Step 4: The lower shock bolts need to be removed next to allow the rear axle to be lowered.

Step 5: Lower the rear axle using the jack.

Step 6: Remove the stock springs and bump stops.

Step 7: Insert the supplied bolts into the so they can be bolted to the lift spacers. See picture below.

Step 8: Tighten down the bump stop so it is attached to the lift spacer.

Step 9: Reinstall the new spacers and bump stops back into the truck.

Step 10: Raise the rear axle back into place and reconnect the rear shocks and sway bar links.

Step 11: Retorque all fasteners after 100 miles.



Terms and conditions

**Please read the following terms and conditions of use before using this product**

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

### Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.