

Toyota Tacoma/Tundra 1" rear lift kit instructions



1. Chock the front wheels and jack up the rear of the vehicle. Support the frame of the vehicle with jack stands. Remove the rear tires and wheels.
2. Support the center of the rear axle with a floor jack and remove lower shock bolts.
3. Making sure the center of the rear axle is balanced on the floor jack, remove the factory U-bolts on both sides of the truck. If you have two floor jacks you can use one on each side and lower the rear axle evenly.
3. You can then lower the rear axle far enough to insert the new rear block making sure the alignment pin is properly seated.
4. Install the supplied u-bolts and hardware and secure to the correct factory torque specs.
5. Install rear shock back into the stock location.

Terms and conditions

Please read the following terms and conditions of use before using this product

All users of this product are subject to the following terms and conditions and other applicable law. If you do not agree with these terms do not use this product. All parts of this product should be assembled or installed by a certified mechanic.

Limitation of Liability

MotoFab or its affiliates shall not be liable for any damages or consequential damages that result from the use of or inability to use the materials on this product or the performance of the product. Even if MotoFab or its affiliates have been advised of the possibility of such damages. Applicable law may not allow the limitation of exclusion of liability or incidental or consequential damages. So the above limitation or exclusion may not apply to you.